



assembly instruction


Mia Dining Chair

MIA-100


Pre - Install Instruction

- Do not FULLY - TIGHTEN the nut or bolt until all nut and bolt is ready assembled
- Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
- Keep all parts & hardware out of reach of children

Parts





A Chair Back x1



B Chair Bracket x1

Hardware

1	JCBC Screw M6 X 25mm		x4
2	Washer		x4
3	Plastic Washer		x4
4	Allen Key M5		x1


Step 1

Parts

- | | | |
|----------|---------------|----|
| A | Chair Back | x1 |
| B | Chair Bracket | x1 |

Hardware

- | | | |
|----------|----------------------|----|
| 1 | JCBC Screw M6 X 25mm | x4 |
| 2 | Washer | x4 |
| 3 | Plastic Washer | x4 |
| 4 | Allen Key M5 | x1 |



Assembly Step Description

Lay down the chair, put both washer before tighten the screw. Tight the screw using allen key.

Thank You For Your Purchase!

Contact us if you need any assistance

018 - 985 4811

018 - 351 4811

customerservice@ruma-home.com

Care Instruction

- Wipe with soft, dry cloth.
- To protect finish avoid the use of chemical cleaners.
- Hardware may loosen over time. Periodically check to make sure all connection are tight.

