
ruma

www.ruma-home.com



assembly instruction


Riko 3 Seater Sofa

R14-81


Pre - Install Instruction

- Do not use power tools.
- Do not over-tight.
- Keep the packing materials and small parts out of reach of children.


Parts



A Sofa x1




B Wooden Leg x4



C Wooden Center Leg x1

Hardware

1 JCBC Screw M8 X 25mm




x8

2 Allen Key M5 X 65mm



x1

3 Plastic Washer M6



x1

ruma

www.ruma-home.com


Step 1

Parts

A	*Sofa	*1
B	*Wooden Leg	*4
C	*Wooden Center Leg	*1

Hardware

1	*JCBC Screw M8x20mm	*8
2	*Allen Key M5x65mm	*1
3	*Plastic Washer M6	*1




Assembly Step Description

Place a wooden leg (B) on to the bottom of the upholstery that you are building. Make sure the hole on the wooden leg (B) aligns with the hole on the bottom of the upholstery. Tighten the wooden leg (B) with the screw (1) by using the allen key(2).

For the center leg, there is hole at the center on the bottom of sofa. Please put the center leg (C) together with plastic washer (3), tighten up the center leg by turn it clockwise.

Thank You For Your Purchase!



Contact us if you need any assistance

018 - 985 4811
018 - 351 4811
customerservice@ruma-home.com

Care Instruction

FOR LEATHER AND P.U (Code"X")

Clean by lightly brushing and vacuuming only to remove dust and particles buildup. Water-based foam cleaner or solvent based cleaning agents of any kind may cause excessive shrinking, staining or distortion of the surface pile and, therefore, should not be used.

FOR FABRIC (Code"WW")

-Use water-based agents only.
-Do not use solvents.
-Gently remove stains by blotting or hang washing.
-Do not use excessive brushing or rubbing.