




assembly instruction


RIKO OTTOMAN

R14-92


Pre - Install Instruction

- Do not use power tools.
- Do not over-tight.
- Keep the packing materials and small parts out of reach of children.

Parts




A Sofa x1



B Wooden Leg x4

Hardware

1 JCBC Screw M8 X 20mm



x8

2 Allen Key M5x65mm



x1


Step 1

Parts

- | | | |
|----------|-------------|----|
| A | *Sofa | *1 |
| B | *Wooden Leg | *4 |

Hardware


- | | | |
|----------|---------------------|----|
| 1 | *JCBC Screw M8x20mm | *8 |
| 2 | *Allen Key M5x65mm | *1 |



Assembly Step Description

Place a wooden leg (B) on to the bottom of the upholstery that you are building. Make sure the hole on the wooden leg (B) aligns with the hole on the bottom of the upholstery. Tighten the wooden leg (B) with the screw (1) by using the allen key(2).

Thank You For Your Purchase!



Contact us if you meet any problem

018 - 985 4811

018 - 351 4811

customerservice@ruma-home.com

Care Instruction

FOR LEATHER AND P.U (Code"X")

Clean by lightly brushing and vacuuming only to remove dust and particles buildup. Water-based foam cleaner or solvent based cleaning agents of any kind may cause excessive shrinking, staining or distortion of the surface pile and, therefore, should not be used.

FOR FABRIC (Code"WW")

- Use water-based agents only.
- Do not use solvents.
- Gently remove stains by blotting or hang washing.
- Do not use excessive brushing or rubbing.